

# SPARE PARTS LIST

MODEL NO. BHP454

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	865306-1	BHP454 NAME PLATE	1	
002	*****	*****	***	*****
003	266130-9	TAPPING SCREW BIND PT 3X16	8	
004	125488-4	SPEED CHANGE LEVER ASSY	1	
005	419250-0	F/R CHANGE LEVER	1	
006	*****	*****	***	*****
007	631692-0	LIGHT CIRCUIT	1	
008	*****	*****	***	*****
009	251468-5	- FLAT HEAD SCREW M6X22	1	
010	*****	*****	***	*****
011	253798-0	FLAT WASHER 13	1	
012	*****	*****	***	*****
013	638613-3	YOKE UNIT	1	
014	619230-8	ARMATURE	1	
015	638614-1	BRUSH HOLDER COMPLETE	1	
016	*****	*****	***	*****
017	263032-0	RUBBER PIN 4	2	
018	450644-0	REAR COVER	1	
019	266130-9	TAPPING SCREW BIND PT 3X16	2	
020	911006-2	PAN HEAD SCREW M3X8	1	
021	689150-0	HEAT SINK	1	
022	232220-0	LEAF SPRING	2	
023	*****	*****	***	*****
024	266045-0	TAPPING SCREW 4X20	4	
025	424026-2	CUSHION	1	
A01	122576-8	STOPPER POLE ASS'Y	1	
A02	*****	*****	***	*****
A03	251314-2	+ SCREW M4X12	2	
A04	*****	*****	***	*****
A05	*****	*****	***	*****
A06	784637-8	+ BIT 2-45	2	
A07	*****	*****	***	*****
A08	*****	*****	***	*****
A09	450128-8	BATTERY COVER	1	
A10	*****	*****	***	*****
A11	*****	*****	***	*****

# SERVICE DRAWING

MODEL NO. BHP454

