

# SPARE PARTS LIST

MODEL NO. BHR202

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	286263-4	CAP 35	1	
002	233940-9	RING SPRING 19	1	
003	417629-9	CHUCK COVER	1	
004	257241-1	RING 21	1	
005	345187-4	GUIDE WASHER	1	
006	233916-6	CONICAL COMP. SPRING 21-29	1	
007	921923-8	HEX. BOLT M8X120	1	
008	345280-4	HEX. WASHER	1	
009	417630-4	GRIP BASE	1	
010	158057-6	GRIP 36 COMPLETE	1	
013	162245-9	CHANGE LEVER	1	
014	233459-8	COMPRESSION SPRING 3	1	
015	419192-8	LOCK BUTTON	1	
016	213278-8	O RING 17	1	
017	158216-2	GEAR HOUSING COMPLETE	1	
018	266351-3	TAPPING SCREW 4X35	4	
019	153290-5	NEEDLE BEARING COMPLETE	1	
020	961017-7	STOP RING E-3	2	
021	417796-0	GUIDE BASE	1	
022	233344-5	COMPRESSION SPRING 4	2	
023	163430-7	LOCK PLATE COMPLETE	1	
024	266374-1	TAPPING SCREW 4X25	2	
025	233929-7	RING SPRING 29	1	
026	*****	*****	***	*****
027	233401-9	COMPRESSION SPRING 32	1	
028	227109-5	SPUR GEAR 51	1	
029	216022-2	STEEL BALL 7.0	1	
030	158574-6	TOOL HOLDER COMPLETE	1	
031	267229-3	FLAT WASHER 28	1	
032	331769-8	SLEEVE 9	1	
033	324669-9	IMPACT BOLT	1	
034	324402-9	RING 10	1	
035	421955-0	CUSHION RING 13	1	
036	324216-6	O RING CASE	1	
037	213073-6	O RING 9	1	
038	233917-4	RING SPRING 28	1	
039	324214-0	STRIKER	1	
040	213227-5	O RING 16	1	
041	318132-2	PISTON CYLINDER	1	
042	267104-3	FLAT WASHER 12	1	
043	324215-8	PISTON JOINT	1	
044	267104-3	FLAT WASHER 12	1	
045	213727-5	O-RING 63	1	
046	211012-0	BALL BEARING 606ZZ	1	
047	961003-8	RETAINING RING S-7	1	
048	233343-7	COMPRESSION SPRING 7	1	
049	227179-4	SPUR GEAR 10	1	
050	324668-1	CAM SHAFT	1	
051	*****	*****	***	*****
052	219014-0	SWASH BEARING 10	1	
053	226632-7	HELICAL GEAR 25	1	
054	266273-7	HEX. SOCKET HEAD BOLT M4X12	2	
055	345179-3	BEARING RETAINER	1	
056	267234-0	FLAT WASHER 8	1	
057	211032-4	BALL BEARING 608ZZ	1	
058	324212-4	RING 8	1	
059	961011-9	STOP RING E-4	1	
060	941102-2	FLAT WASHER 5	1	
061	233342-9	COMPRESSION SPRING 6	1	
062	345363-0	CHANGE PLATE	1	
063	*****	*****	***	*****

# SPARE PARTS LIST

MODEL NO. BHR202

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
064	443126-9	FELT	1	
065	213407-3	O RING 26	1	
066	213077-8	OIL SEAL 10	1	
067	210059-1	BALL BEARING 6000DDW	1	
068	267213-8	FLAT WASHER 10	1	
069	240092-9	FAN 64	1	
070	519226-8	ARMATURE ASS'Y 18V INC. 67-69,71,72	1	
071	253823-7	FLAT WASHER 7	1	
072	210023-2	BALL BEARING 627DDW	1	
073	267816-8	WAVE WASHER 15	1	
074	865285-3	BHR202 NAME PLATE	1	
075	188515-8	HOUSING SET INC. 82	1	
076	638020-0	YOKE UNIT	1	
077	643834-4	BRUSH HOLDER	1	
078	643835-2	BRUSH HOLDER	1	
079	266326-2	TAPPING SCREW 4X18	2	
080	911006-2	PAN HEAD SCREW M3X8	1	
081	689070-8	HEAT SINK	1	
082	188515-8	HOUSING SET INC. 75	1	
083	424128-4	HOLDER CAP COVER	2	
084	643829-7	HOLDER CAP	2	
085	194435-6	CARBON BRUSH CB-441	1	
086	424111-1	SWITCH COVER	1	
087	450615-7	F/R CHANGE LEVER	1	
088	*****	*****	***	*****
089	631792-6	LIGHT CIRCUIT	1	
090	266326-2	TAPPING SCREW 4X18	7	
091	*****	*****	***	*****
092	*****	*****	***	*****
093	263036-2	RUBBER PIN 5	1	
094	268184-2	PIN 1.5	1	
095	*****	*****	***	*****
096	266326-2	TAPPING SCREW 4X18	2	
097	424042-4	CUSHION RUBBER	1	
098	424026-2	CUSHION	1	
099	424042-4	CUSHION RUBBER	1	
100	*****	*****	***	*****
A01	324219-0	DEPTH GAUGE	1	
A02	*****	*****	***	*****
A03	450128-8	BATTERY COVER	1	
A04	*****	*****	***	*****
A05	*****	*****	***	*****

# SERVICE DRAWING

MODEL NO. BHR202

