


SERVICE DRAWING

MODEL NO. BMR102



SPARE PARTS LIST

MODEL NO. BMR102

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	*****	*****	***	*****
002	SE09163102	SCREWM3X10	5	
003	*****	*****	***	*****
004	SE09163102	SCREWM3X10	6	
005	SE09090011	SCREW1.7	13	
006	SE020PC020	POWERBUTTONHOLDER	1	
007	SE00000157	POWERBUTTON(GRY)	1	
008	SE020PC030	PRESETBUTTONHOLDER	1	
009	SE00000158	PRESETBUTTON(GRY)	1	
010	SE09064161	SCREWM4X16	1	
011	SE09163102	SCREWM3X10	2	
012	SE09064161	SCREWM4X16	2	
013	SE00000204	FRONTCABINETASSY	1	
015	SE09064161	SCREWM4X16	1	
016	SE00000159	FRONTBUMPER	1	
017	SE0338PC5Z	FRONTBAR	2	
018	SE00000160	SCREWPTHE6X47(CR)	4	
019	SE00000161	ROTARYKNOB	1	
020	SE21B1110A	ROTARYKNOBRING	1	
021	SE0335PC5Z	JACKCOVER	1	
022	SE09173106	HEXSCREWM3X10	1	
023	SE00000162	BATTERYCOVERBUMPER	1	
024	SE09176166	HEXSCREWM6X16	2	
025	SE09176166	HEXSCREWM6X16	2	
026	SE00000165	REARBUMPER	1	
027	SE00000166	BATTERYCOVER	1	
028	SE09163102	SCREWM3X10	2	
029	SE00000168	PACKING	1	
030	SE00000169	SUPPORTBAR	1	
031	SE00000170	SPRING-L	1	
032	SE00000171	SPRING-R	1	
033	SE09163102	SCREWM3X10	2	
034	SE00000173	SPRINGHOLDER-R	1	
035	SE09163102	SCREWM3X10	2	
036	SE00000175	SPRINGHOLDER-L	1	
037	SE0307PC5Z	BACKUPBATTERYCOVER	1	
038	SE021E9010	BATTERYCONTACT(+)	1	
039	SE021E9020	BATTERYCONTACT(-)	1	
040	SE021E9030	+/-BATTERYCONTACTASS'Y	1	
041	SE09163452	SCREWM3X45	1	
042	SE00000176	SCREWPTHE6X20(CR)	1	
043	SE00000177	HANDLEHOLDER(R)	1	
044	SE00000179	HANDLE	1	
045	SE00000180	HANDLEHOLDER(L)	1	
046	SE00000176	SCREWPTHE6X20(CR)	1	
047	SE09176166	HEXSCREWM6X16	1	
048	SE00000184	SPRING	2	
049	SE09994007	STEELBALL	2	
050	SE09994007	STEELBALL	2	
051	SE00000184	SPRING	2	
052	SE09176166	HEXSCREWM6X16	1	
053	SE00000187	HANDLESUS-PLATE(R)	1	
054	SE09163452	SCREWM3X45	1	
055	SE00000188	REARCABINET	1	
056	SE00000067	LOCKERHINGER	1	
057	SE00000190	BATTERYCOVERLOCKER	1	
058	SE021PC050	LOCKERFIXERPIN63.8	1	
059	SE021PC040	LOCKERFIXERPIN79.5	1	
060	SE00000191	RODANT(BLK)	1	

SPARE PARTS LIST

MODEL NO. BMR102

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
061	SE021J9032	RODANTHOLDER	1	
062	SE024J9050	PACKING	1	
063	SE00000192	HANDLESUS-PLATE(L)	1	
064	SE021P0020	NUT	1	
065	SE021PC100	RODANTTERMINAL	1	
066	SE00000193	SCREW3X10	2	
067	SE024J9030	PACKING	1	
068	SE024J9070	PACKING	4	
069	SE09090023	SCREWM4X12	4	
070	SE00000205	SPEAKERNETASSY	1	
071	SE024J9090	PACKING	4	
072	SE024J9040	PACKING	4	
073	SE9076146A	HEXSCREWM6X14	4	
074	SE023PC020	EVA25X18X5.5	1	
075	SE021J9010	SPEAKERHOLDER	1	
076	SE024PC040	PACKING	1	
077	SE00000195	W/TIES100MM	1	
078	SE09163102	SCREWM3X10	1	
079	SE09163102	SCREWM3X10	2	
080	*****	*****	***	*****
081	SE09163102	SCREWM3X10	2	
082	SE00000197	TERMINALD	1	
083	SE00000193	SCREW3X10	2	
084	SE00000199	SILICONRUBBERWASHER	2	
085	SE00000193	SCREW3X10	2	
086	SE09163062	SCREWM3X6	2	
087	SE00000200	TERMINALC	1	
088	SE023PC020	EVA25X18X5.5	2	
089	SE02311000	SPACER(A)	1	
090	SE021J9010	SPEAKERHOLDER	1	
091	SE024J9030	PACKING	1	
092	SE024J9070	PACKING	4	
093	SE09090023	SCREWM4X12	4	
094	SE024J9090	PACKING	4	
095	SE00000205	SPEAKERNETASSY	1	
096	SE024J9040	PACKING	4	
097	SE9076146A	HEXSCREWM6X14	4	
098	SE021PC030	BATTERYCOVERLOCKER	1	
099	SE00000193	SCREW3X10	2	
100	SE01620771	SPEAKER	1	
101	SE01620771	SPEAKER	1	
A01	SE00000078	ACADAPTER3A8D127102B11	1	