

SPARE PARTS LIST

MODEL NO. BPB180

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	922456-6	HEX. SOCKET HEAD BOLT M8X35	2	
002	941202-8	FLAT WASHER 8	2	
003	273525-9	GRIP	1	
004	210033-9	BALL BEARING 696ZZ	1	
005	256033-5	PIN 6	1	
006	265999-8	TAPPING SCREW 4X25	2	
007	266147-2	TAPPING SCREW 4X55	2	
008	272223-2	LEVER 60	1	
009	267041-1	FLAT WASHER 20	1	
010	158703-1	FRONT WHEEL COVER COMPLETE	1	
011	210033-9	BALL BEARING 696ZZ	1	
012	941152-7	FLAT WASHER 6	1	
013	210033-9	BALL BEARING 696ZZ	1	
014	251337-0	+ PAN HEAD SCREW M5	1	
015	317824-0	UPPER HOLDER	1	
016	266034-5	TAPPING SCREW CT 4X16	2	
017	256033-5	PIN 6	1	
018	210033-9	BALL BEARING 696ZZ	1	
019	343494-9	SLEEVE 5	1	
020	163276-1	SLIDE PLATE	1	
021	231449-5	COMPRESSION SPRING 11	1	
022	210033-9	BALL BEARING 696ZZ	1	
023	941152-7	FLAT WASHER 6	1	
024	210033-9	BALL BEARING 696ZZ	1	
025	251337-0	+ PAN HEAD SCREW M5	1	
026	343494-9	SLEEVE 5	3	
027	941051-3	FLAT WASHER 4	3	
028	266034-5	TAPPING SCREW CT 4X16	3	
029	231449-5	COMPRESSION SPRING 11	1	
030	343489-2	TENSION PLATE	1	
031	911221-8	PAN HEAD SCREW M5X16	1	
032	421333-4	RUBBER TIRE	1	
033	253749-3	FLAT WASHER 16	1	
034	152325-9	WHEEL COMPLETE	1	
035	253749-3	FLAT WASHER 16	1	
036	253010-8	FLAT WASHER 6	1	
037	922312-0	HEX. SOCKET HEAD BOLT M6X12	1	
038	210033-9	BALL BEARING 696ZZ	1	
039	941152-7	FLAT WASHER 6	1	
040	210033-9	BALL BEARING 696ZZ	1	
041	251337-0	+ PAN HEAD SCREW M5	1	
042	251337-0	+ PAN HEAD SCREW M5	1	
043	210033-9	BALL BEARING 696ZZ	1	
044	941152-7	FLAT WASHER 6	1	
045	210033-9	BALL BEARING 696ZZ	1	
046	256033-5	PIN 6	1	
047	210033-9	BALL BEARING 696ZZ	1	
048	317823-2	LOWER HOLDER	1	
049	266034-5	TAPPING SCREW CT 4X16	2	
050	418784-0	SAW GUARD HOLDER	1	
051	266042-6	TAPPING SCREW BIND CT 4X20	2	
052	421333-4	RUBBER TIRE	1	
053	266021-4	TAPPING SCREW 5X20	3	
054	154949-7	GEAR COMPLETE	1	
055	419506-1	WHEEL	1	
056	324513-0	LOWER SHAFT	1	
057	253749-3	FLAT WASHER 16	1	
058	253010-8	FLAT WASHER 6	1	
059	922312-0	HEX. SOCKET HEAD BOLT M6X12	1	
060	253749-3	FLAT WASHER 16	1	
061	922323-5	HEX.SOCKET HEAD BOLT M6X16	1	

SPARE PARTS LIST

MODEL NO. BPB180

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
062	266203-8	TAPPING SCREW BIND CT 4X40	1	
063	266147-2	TAPPING SCREW 4X55	2	
064	266048-4	TAPPING SCREW 4X40	2	
065	317947-4	REAR WHEEL COVER	1	
066	265995-6	TAPPING SCREW 4X18	8	
067	265995-6	TAPPING SCREW 4X18	2	
068	911243-8	PAN HEAD SCREW M5X25	2	
069	188108-1	HANDLE SET INC. 72	1	
070	911213-7	PAN HEAD SCREW M5X12	4	
071	168412-4	REAR BUMPER	1	
072	188108-1	HANDLE SET INC. 69	1	
073	232201-4	LEAF SPRING	1	
074	419504-5	LOCK OFF BUTTON	1	
075	650229-4	SWITCH SGE120C-3	1	
076	227170-2	SPUR GEAR 12	1	
077	962203-3	RETAINING RING R-47	1	
078	211306-3	BALL BEARING 6204LLB	1	
079	227470-0	SPIRAL BEVEL GEAR 29	1	
080	254202-2	KEY 4	1	
081	*****	*****	***	*****
082	227481-5	SPIRAL BEVEL GEAR 11	1	
083	*****	*****	***	*****
084	961055-9	RETAINING RING S-15	1	
085	226626-2	HELICAL GEAR 45	1	
086	*****	*****	***	*****
087	252157-5	SQUARE NUT M6	2	
088	345467-8	STOPPER PLATE	1	
089	251981-3	HEX. SOCKET HEAD BOLT M6X16	2	
090	154475-6	GEAR HOUSING COMPLETE	1	
091	619187-3	ARMATURE	1	
094	638420-4	YOKE UNIT	1	
095	*****	*****	***	*****
096	188107-3	HOUSING SET INC. 97	1	
097	188107-3	HOUSING SET INC. 96	1	
098	643929-3	BRUSH HOLDER CAP	2	
099	191971-3	CARBON BRUSH CB-430	1	
100	*****	*****	***	*****
101	643812-4	TERMINAL	1	
102	213261-5	O RING 17	1	
103	419505-3	DIAL	1	
104	862499-5	BPB180 NAME PLATE	1	
106	168413-2	FRONT BUMPER	1	
107	266042-6	TAPPING SCREW BIND CT 4X20	2	
108	418784-0	SAW GUARD HOLDER	1	
109	266034-5	TAPPING SCREW CT 4X16	1	
110	*****	*****	***	*****
A03	B-10350	BAND SAW BLADE 18 BIMETAL	1	
A04	783202-0	HEX. WRENCH 4	1	
A05	824766-6	PLASTIC CARRYING CASE	1	

SERVICE DRAWING

MODEL NO. BPB180

